INTEX® OWNER'S MANUAL

Quick-Fill™ Electric Air Pump

Model AP619-III; 110 - 120 Volt ~ 60 Hz; 0.95 A

READ AND FOLLOW ALL INSTRUCTIONS BEFORE USING THIS PRODUCT

- For Indoor Household Use Only.
- Adult use only.
- Do not drop unit into water or expose unit to rain or water.
- Do not direct air stream at face or body.
- Do not operate for more than 10 minutes at a time. Unplug and let cool at least 10 minutes.
- Unplug unit when not in use
- Do not obstruct vent holes or open source.
- Do not insert objects into the inflation or deflation connector.
- The AC supply cord cannot be replaced. If the cord is damaged the appliance should be scrapped.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.

FOLLOW THESE RULES AND ALL INSTRUCTIONS TO AVOID PROPERTY DAMAGE, ELECTRIC SHOCK, BURNS OR OTHER INJURY.


To reduce the risk of electric shock or injury, use indoors only, do not expose to rain. Store indoors

SERVICING OF A DOUBLE-INSULATED PRODUCT:

In a double-insulated product, two systems of insulation are provided instead of grounding. No grounding means is provided on a double-insulated product, nor should a means for grounding be added to the product. Servicing of a double-insulated product requires extreme care and knowledge of the system, and should be done only by qualified service personnel. Replacement parts for a double-insulated product must be identical to those parts in the product.

A double-insulated product is marked with the words "DOUBLE INSULATION" or "DOUBLE INSULATED" and with the symbol .

NAMES OF PARTS



PARTS DESCRIPTION:

- **PUMP**
- INFLATION CONNECTOR DEFLATION CONNECTOR
- **SWITCH**
- AC LINE CORD
- NO77LFS
- **VENT HOLES / SLOTS**

NOTE: Drawings for illustration purpose only. Actual product may vary. Not to scale.

OPERATING INSTRUCTIONS

General

- This appliance has a polarized plug (one blade is wider than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet. Do not change the plug in any way.
- Return pump and nozzles to package when not in use.

READ AND SAVE THESE INSTRUCTIONS

202-***-R0-1504

OPERATING INSTRUCTIONS


202

INFLATION

1. Attach nozzle to the inflation connector if necessary and hold pump against inflation valve on item to be inflated.

NOTE: On large items like inflatable boats and large air mattresses, the pump will fit directly into the inflation valves and provide faster inflation times. Use the appropriate nozzle on small inflation valves as on small air mattresses, etc.

- 2. Plug in the AC line cord into an AC electrical outlet. See Fig (2).
- 3. SWITCH ON: Press "I"; SWITCH OFF: Press "0". See Fig (3).




DEFLATION

1. Attach nozzle to the deflation connector if necessary and hold pump against inflation valve on item to be deflated.

NOTE: On large items like inflatable boats and large air mattresses, the pump will fit directly into the inflation valves and provide faster deflation times. Use the appropriate nozzle on small inflation valves as on small air mattresses, etc.

- 2. Plug in the AC line cord into an AC electrical outlet. See Fig (2).
- 3. SWITCH ON: Press "I"; SWITCH OFF: Press "0". See Fig (3).



MAINTENANCE INSTRUCTIONS

No specific air pump maintenance is required. Air pump has no user serviceable parts.

MOVING AND STORAGE INSTRUCTIONS

Move the product, air pump and accessories to the power source location. Make sure the power cord is free of twist, kink and knot. Fold the power cord loosely, and return pump and nozzles to package when not in use.

> ©2014 Intex Marketing Ltd. - Intex Development Co. Ltd. - Intex Trading Ltd. - Intex Recreation Corp. All rights reserved/Tous droits réservés/Todos los derechos reservados/Alle Rechte vorbehalten. Printed in China/Imprimé en Chine/Impreso en China/Gedruckt in China.

Printed in Chinalmprime en Chine/impress en Chinal-dedruckt in China.

Oir Trademaris used in some outnities of the world under license Itonio.

Mauques ullisées dans certains pays sous licence delMarcas registradas utilizadas en algunos países del mundo bajo licencia delMarcas registradas utilizadas en algunos países del mundo bajo licencia delMarcas registradas utilizadas en algunos países del mundo bajo licencia delMarcas registradas utilizadas en algunos países del mundo bajo licencia delMarcas registradas utilizadas en algunos países de mundo bajo licencia delMarcas registradas utilizadas en algunos países dans utilizadas en algunos países European Union Dy/Distribute data is contact. Supposed.

4705 RR Roosendaal – The Netherlands www.intexcorp.com

FIG (2)

