



*★ For An Additional One Year Guarantee ★
Please Register Your Appliance
At*

www.warmlite.co

*and enjoy the peace of mind
of a*



Product Helpline. 0871 221 3618 For all your product needs.



INSTRUCTION MANUAL



Folding Quartz Heater

WL42006



Product may differ slightly from Image

TECHNICAL DATA

Model: WL42006

Voltage:

220V-240V ~50Hz

Power consumption:

800W (400W+400W)

SUTTON HOUSE
BERRYHILL ROAD
FENTON

STOKE ON TRENT

STAFFORDSHIRE


ST4 2NL

UK POSTAL ADDRESS **ONLY**



DO NOT COVER

PARTS IDENTIFICATION



A. Carrying handle

B. Quartz Heating Elements

C. Stabilising Foot

D. Power control switch (selects the number of elements are on)

E. Tilt Switch (switches the fire off when it is tilted accidentally)

F. Power plug and cable

IMPORTANT INFORMATION

Caution

Remove the packing and make sure that the appliance is intact before switching on. Do not leave packaging materials within reach of children.

Before switching on appliance check if the household electrical supply is compatible with the appliance



WARNING: DO NOT COVER

WARNING: Before cleaning the appliance or carrying out any maintenance ensure that the appliance is switched off and that the plug is removed from the socket.

WARNING: This heater is not equipped with a device to control the room temperature. Do not use this heater in small rooms when they are occupied by persons not capable of leaving the room on their own, unless constant supervision is given.

WARNING: Not suitable for use in bathroom.

For Household use only

The manufacture is not responsible for any eventual damages caused by improper or faulty use.

Never touch the appliance with wet or damp hands or feet.

Never expose the appliance to atmospheric conditions (rain, sun, etc.)

The appliance must be always placed on a flat and stable surface.

When the appliance is not in use switch it off and unplug it.

Do not use this heater in the immediate surroundings of a bath, a shower or a swimming pool.

Do not put the cable on the appliance when it still warm.

Do not switch on the heater near pieces of furniture, curtains, shelves, etc.

Do not use the appliance near combustible materials

The appliance must not be located immediately below a socket outlet.

In case the power cord is damaged, send it to the nearest after sale service recommended by the manufacturer or qualified electrician for the replacement.

This appliance is NOT intended use by children or the infirm unless they have been given adequate training or instruction concerning use of the appliance

Children should be supervised to ensure that they do not play with the appliance.

Do not connect the appliance to extension cords or multiple outlets.

Do not damage and do not kink the power cord.

Do not use this heater with a programmer, timer or any other device that switches the heater on automatically, since a fire risk exists if the heater is covered or positioned incorrectly.

Electrical Safety


Class 1 Configuration

The wires in the mains lead are coloured in accordance with the following code:

GREEN/YELLOW: EARTH (E)

BLUE: NEUTRAL (N)

BROWN: LIVE (L)



Class 1 Configuration

As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The wire which is coloured GREEN & YELLOW (or coloured GREEN) must be connected to the terminal in the plug which is marked with the letter “E” or by the earth symbol $\equiv$.

The wire which is coloured BLUE (or coloured BLACK) must be connected to the NEUTRAL terminal which is marked with the letter “N”.

The wire which is coloured BROWN (or coloured RED) must be connected to the LIVE terminal which is marked with the letter “L”.

Always ensure that the Mains Cord is fixed into the plug through the Cord Guard or Cable Clamp, (plug wiring diagram above), and that the Cord Guard screws are tightened to clamp the cord (outer sheath and inner coloured wires) into position in the plug.

Make sure that the plug top is also fitted securely.

This appliance must be protected by a 5 Amp fuse in a 13 Amp type (BS1363) plug. Should you need to replace the fuse, use only a 5Amp ASTA approved BS1362 fuse (13A).

OPERATIONAL GUIDELINES

It is important to ensure the correct Plug Adaptor is used when operating in a country not using the UK 13 Amp socket system. If in doubt, consult a qualified electrician.

OPERATION

Plug in the appliance. Check that the outlet has at least a 10Amp current carrying capacity.

SAFETY DEVICE

This appliance is provided with safety devices disconnects the appliance when the heater is tilted or when is tipped by means of a switch situated in the lower part of the radiator.

MAINTENANCE

The appliance needs only an external regular cleaning.

After use and before cleaning always unplug the appliance and wait till the item has cooled completely.

Clean the grilles from dust.

Do not clean the painted parts with abrasive cleaners or solvents and use only a moistened soft cloth.

GUARANTEE

THIS PRODUCT IS GUARANTEED FOR 12 MONTHS FROM THE DATE OF THE ORIGINAL PURCHASE.

IF ANY DEFECT ARISES DUE TO FAULTY MATERIALS OR WORKMANSHIP, THE FAULTY PRODUCT MUST BE RETURNED TO THE PLACE OF PURCHASE.

REFUND OR REPLACEMENT IS AT THE DISCRETION OF THE RETAILER.

THE FOLLOWING CONDITIONS APPLY:

THE PRODUCT MUST BE RETURNED TO THE RETAILER WITH THE PROOF OF PURCHASE.

THE PRODUCT MUST BE INSTALLED AND USED IN ACCORDANCE WITH THE INSTRUCTIONS CONTAINED IN THIS INSTRUCTION GUIDE.

THIS ITEM IS FOR DOMESTIC PURPOSES ONLY.

THIS GUARANTEE DOES NOT COVER WEAR AND TEAR, DAMAGE, MISUSE OR CONSUMABLE PARTS

PFD HAS LIMITED RESPONSIBILITY FOR INCIDENTAL OR CONSEQUENTIAL LOSS OR DAMAGE. VALID IN THE UK AND EIRE ONLY.

Declaration of Conformity

WE PFD LTD DECLARE THAT THIS PRODUCT CONFORMS TO THE FOLLOWING PRODUCT LEGISLATION IN ACCORDANCE WITH THE FOLLOWING DIRECTIVE(S):

2004/108/EEC. THE EMC DIRECTIVE (THE ELECTROMAGNETIC COMPATIBILITY DIRECTIVE).

2006/95EC. THE LVD DIRECTIVE (LOW VOLTAGE DIRECTIVE).

THE ROHS DIRECTIVE (RESTRICTION OF HAZARDOUS SUBSTANCES DIRECTIVE).

PETER BOWDEN

QUALITY ASSURANCE MANAGER.

SUTTON HOUSE, BERRYHILL ROAD, FENTON, STOKE-ON-TRENT,
STAFFORDSHIRE, UK. ST4 2NL

UK POSTAL ADDRESS **ONLY**

DISPOSAL



DISPOSAL INSTRUCTIONS FOR WARMLITE ITEMS IN ACCORDANCE WITH THE WEEE DIRECTIVE.

APPLIANCES BEARING THE SYMBOL SHOWN ABOVE MAY NOT BE DISPOSED OF IN DOMESTIC RUBBISH.

YOU ARE REQUIRED TO DISPOSE OF THE OLD ELECTRICAL AND ELECTRONIC APPLIANCES LIKE THIS SEPARATELY, PLEASE VISIT :

WWW.RECYCLEMORE.CO.UK OR WWW.RECYCLENOW.CO.UK

FOR ACCESS TO INFORMATION ABOUT THE RECYCLING OF ITEMS.

THE WEEE DIRECTIVE, INTRODUCED IN AUGUST 2006 STATES THAT ALL ELECTRICAL ITEMS MUST BE RECYCLED RATHER THAN TAKEN TO LANDFILL.

PLEASE ARRANGE TO TAKE THIS APPLIANCE TO YOUR LOCAL REFUSE CENTRE.