

Owner's Manual CONTACT US

Questions? Need parts?

We are here to help!

Permasteel Customer Service

Tel: 888-287-0735

Fax: 909-287-0733

Email: service@permasteel.net

Monday-Friday

8:00am-5:00pm (Pacific Standard Time)



STEEL 80QT COOLER MODEL#PS-206


ASSEMBLY INSTRUCTIONS:

TOOLS REQUIRED:

#2 Phillips screwdriver

Allen wrench

Please read the cooler manual carefully and assemble according to following steps.



| Item | Description | Quantity |
|------|--------------------|----------|
| 1 | Lid Handle | 2 |
| 2 | Lid | 2 |
| 3 | M5*40 Screw | 2 |
| 4 | M6*12 Allen Scre | 12 |
| 5 | Handle | 2 |
| 6 | M6*12 Allen screw | 2 |
| 7 | Bottle Opener | 1 |
| 8 | Bottle-cap catcher | 1 |
| 9 | Basin | 1 |
| 10 | leg | 4 |
| 11 | bottom shelf | 1 |
| 12 | wheel without lock | 2 |
| 13 | wheel with lock | 2 |
| | M6 Allen wrench | 1 |

- 1. Please make sure all parts are accounted for before beginning assembly.
- 2. Place main basin up-side down on clean soft surface insert each leg(part 10) and rotate into main basin by hand, after 4 legs are installed, then put the bottle tray on each leg, then rotate each wheel(parts 12&13) into the leg with an open wrench
- 3. Turn over entire assembly right side-up press caster brake lever to lock casters (part 12) insert right handle (part 5) into bracket attach using 6 pcs M6*12 Allen screws (parts 3) with a Allen wrench. Repeat for left handle.
- 4. Attach bottle-cap catcher (parts 9) to main basin by sliding it down over 2 preinstalled bolts,
- 5. Attach bottle opener (parts 7) to main basin using 2pcs M6*12 Allen screws with a Allen screwdriver.
- 6. Attach 2pcs lid handles (parts 1) to cooler lid by using 2pcs 5/32x1/2" screws with a Philips screwdriver.
- 7. Clean inside of cooler completely with soft dry towel. Place cooler lid (2) on top of main basin (A) your cooler is now ready for use.